

BarbLock®

BarbLock Corporation

BarbLock® Tool Data Sheet (BL2)

BarbLock® Tools

Part Name: Universal Removal Tool

Part Number: BLT-URT

The Universal Removal Tool has been configured to slit the Sleeve allowing for the Sleeve to be peeled from the Collet. The design permits the safe removal of the BarbLock® assembly without damaging the tube or fitting.

Removal sequence: Starting with the BarbLock® assembly

1. Always wear safety glasses when using BarbLock® Tools.
2. Place the assembled BarbLock® between the jaws. (Diagram A)
3. Make sure the hooked portion of the upper jaw is sitting on top of the sleeve. (Diagram A)
4. Ensure the base of the Sleeve is sitting in the dished portion of the lower jaw. (Diagram A)
5. Continue closing the pliers with a ratcheting motion until the pliers are closed
6. Make a second cut on the opposite side of the assembly using the same technique.
7. Wearing a pair of gloves, safely peel off the Sleeve from the assembly and remove the Collet.
8. It may be necessary to repeat the above process to safely remove the BarbLock® Collet.

Disclaimer: BarbLock® endorses the proper use of hand tools. BarbLock® tools should only be used in the manner described within the BarbLock® Tool Data Sheet. Always keep your hands away from the jaws and moving parts during operation. BarbLock® makes no claim as to the design, manufacture, or contractual relationship relating to Western Forge, Inc.

BarbLock® Tools are guaranteed for life against material defects. Service & Returns: 877-655-4481

*Base Tool: Robo Grip 7-inch pliers

**Modified Jaws shaped for Sleeve removal

BarbLock Corporation is the sole manufacture of BarbLock® tools / BarbLock® tools are Patented / All Rights Reserved

